

# GOLD EVOLUTION EXT Installation Kit

### How to Use GOLD EVOLUTION EXT Installation Kit

GOLD EVOLUTION EXT Installation Kit provides enough adhesive and colored hardener to bond at least (2) standard seams.

#### Important: Pre-Application Testing

Before beginning your installation:

- Be sure to TEST each substrate for bonding and appearance before the actual application. For best results, all contact surfaces must be clean and dry.
- Dispense a bead of adhesive into the designated area on the mixing board.
- Dispense a bead of colored hardener into the designated area on the mixing board. (Shake well / knead tube before each use).
- Thoroughly mix the adhesive and colored hardener inside the printed oval for 45-60 seconds before applying.
- To ensure complete bonding, be sure the adhesive is applied, and the two pieces of stone are clamped together within 3-5 minutes.